

INSTRUCTIONS FOR HAND VENEER TAPER

AM

4/7/98 - Veneer Taper Instructions.cdr

1. Place two pieces of veneer next to each other as if to be taped. Run the taper up the seam to determine if the two front wheels are set properly. They should pull the two pieces of veneer together to make a butt joint. The front two wheels should be pointing out to make a V. This will cause the veneer to be pulled to the center as the taper is rolled along the joint. If they are not being pulled together loosen the wheels and re-tighten the bolt.
2. Remove the wing nut and take cover plate off. Add water to the sponge. The roll of paper tape should be installed with the adhesive side up. If not, reverse the roller of tape.
3. The paper tape runs under the rear large roller and presses it to the veneer as you roll forward. When you get to the end of the veneer, hold the tape to the veneer with one hand, squeeze the handle with the other and give a quick jerk.

CALL 800 547-5484 with any Questions

Quality VAKuum Products, Inc. 43 Bradford St. - Concord, MA 01742
Tel: 978-369-2949 - Fax: 978-369-2928